

Padlock Usage

General Usage



- 1 If the lock is in the locked state, insert a charged and coded OneKEY into the IR port on the bottom of the lock and press the button. Hold the key in place until the confirmation beep & the LED goes out.



- 2 Once the key has beeped in confirmation pull the shackle out from the lock body.



- 3 Insert the shackle through the object that will be secured.



- 4 Swivel the lock body so that the hole is aligned with the shackle.

Weather Sleeve Installation Steps



- 5 Close the padlock to secure the object. To open the padlock, use a charged and coded OneKEY as shown in step 1. Pull on the lock body to ensure that it is locked.



- 6 Insert the shackle into the bottom of the cover.



- 7 Carefully fit the cover around the top of the lock body.
Note: Do NOT pull on the separate tab to prevent tearing the cover.



- 8 Continue carefully working the cover down onto the lock body.

Padlock Usage



9 Work the cover fully down onto the lock body so that the cover sits against the top of the lock as shown.



10a If using a padlock with an anti-cut cover and its corresponding weather cover, ensure that when installing, the logos on the padlock and weather cover are facing in the same direction.



10b Ensure that the cover fully sits on the padlock as shown.



11 Insert the plug at the end of the tab into the IR port to protect the port from moisture and debris.



12 To remove the cover, unplug the tab and begin carefully rolling the cover up the lock body.



13 Continue rolling the cover up the lock body.



14 Remove the cover.



15 Turn the cover rightside out to reuse the cover on another lock.

Padlock Usage

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.